
Samsung Blackjack Battery Replacement

Replace the battery on your Samsung Blackjack.

Written By: Kristin Manna



INTRODUCTION

Use this guide to replace the battery.

Step 1 — Battery Cover






- Hold the device with the screen facing away from you and the camera towards you.
- Place your thumb on the bottom half of the phone and slide the cover off while gently pushing down on the cover.

Step 2 — Battery





- Place your fingers on both sides of the bottom of the battery and lift upwards.
- Pull the battery away from the phone.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-30 12:28:24 PM.